Protocol & Procedure for Placement of the OCO Biomedical Macro™ Two-Stage Implant

A - #8 High-speed Surgical Bur

B - 1.8mm Pilot Drill

C - Drill Stop

D - Paralleling Pin

E - Tissue Punch

F - Final Drill - Upper or Lower

G - Macro™ Driver

H - Macro™ Two-Stage Implant

Proper Drill Sequence for Macro™ Two-Stage Implant (6.0 & 7.0mm diameters)

1 - #8 High-speed Surgical Bur - Penetrate soft tissue if flapless, otherwise use to divot crest

2 - 1.8mm Pilot Drill - Place drill stop onto pilot drill and drill full length stopping at soft tissue

3 - Paralleling Pin - Place paralleling pin to evaluate implant size and trajectory

4 - Tissue Punch - Remove soft tissue if placing implant flapless

5 - 1.8mm Pilot Drill - Take pilot drill to full length of intended implant

6 - Final Drill - Take final drill to full length of osteotomy*

7 - Macro™ Driver - Drive implant into final position

**Macro™ implants must have osteotomy created by stepping up in serial progression*

For questions on the Macro™ implant placement and restorative techniques please visit www.ocobiomedical.com, call 800-228-0477, +1 (505)-293-0025 international or email sales@ocobiomedical.com.

OCO Biomedical
9550 San Mateo Blvd. NE, Suite C
Albuquerque, NM 87113
www.ocobiomedical.com

Toll Free: (800) 228-0477
International: + 1(505) 293-0025
Direct: (505) 293-0025
Fax: (505) 293-0447

Designed and Manufactured in USA
U.S. Patent: US 8,277,218,B2
ISO 13485:2003 CERTIFIED
CE 0086
EC REP Wellkang Ltd Suite B, 29 Harley Street LONDON, W1G 9QR, U.K.
349-5 09/16