



All drilling must be done under a constant stream of sterile integration using a pumping motion to prevent over-heating the bone. Surgical Drills should be replaced when they are dull, corroded or compromised in anyway. OCO Biomedical recommends replacing drills after 15-20 osteotomies.

[illegible]

FRM-25-09 Rev.1